



YAMAHA

PARTS CATALOGUE

JMPB

DT50MX'81 (5M3)


HOLLAND

parts

115M3-341E1




A3



JMPB

parts



CA

FOREWORD

This Parts Catalogue is related to the parts in use for the Yamaha DT 50MX '81 (5M3).
When you are ordering replacement parts for the DT 50MX '81 (5M3), refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after issue of the Parts Catalogue will be announced in the Yamaha Parts News.
It is advisable that according to the Yamaha Parts News you make necessary corrections to the Parts Catalogue on hand to keep it up-to-date.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

U.R.	Use size (thickness) and/or number as required.
U.N.	Use as many as you need.
A.P.	Alternate Parts
L.M.	Local Made
F#	Frame No. (Applicable machine No.)

3. The parts marked with (*) in the parts number column of this Catalogue are not supplied with by Yamaha, those have to be found locally.
4. Parts, which are to be supplied in the form of assemblies, are listed with an indentation of one letter's space, and a dot (.) is put against the name of each part.

EXAMPLE CARBURETOR ASS'Y

- . JET, pilot
- . NOZZLE, main

5. Indication of No. of constituent parts for assembly



The numeral appearing to the right of each constituent part under the description indicates the quantity of such parts for each individual assembly unit.

EXAMPLE

Part No.	Description	Q'ty	Remarks
2F5-83310-60	FRONT FLASHER LIGHT ASS'Y	2	
115-83311-60	. BULB (6V-18W)	1	
1M1-83309-60	. REFLECTOR	1	

6. Initial Serial No. and Color Code

(A) Frame Serial No.	5M3-000101 and following
(B) Engine Serial No.	5M3-000101 and following



Color Code	Color Name	Abbreviate
33	Yamaha Black	YB
36	White	W
E1	Chappy Red	CPR

7. Applicable colors of graphics are represented in the "Remarks" column by the letter(s) appropriately picked out of the full word(s) showing such colors.

EXAMPLE

Part No.	Description	Q'ty	Remarks
2N4-24110-00-X5	FUEL TANK COMP.	1	MAXIM RED
3J1-24240-10	. GRAPHIC, fuel tank set	1	for MXR

CONTENTS

ENGINE

Fig. 1	Cylinder Head - Cylinder	1
Fig. 2	Crankshaft - Piston	2
Fig. 3	Flywheel Magneto	3
Fig. 4	Oil Pump	4
Fig. 5	Intake	5
Fig. 6	Carburetor	6
Fig. 7	Exhaust	8
Fig. 8	Crankcase	9
Fig. 9	Crankcase Cover	10
Fig. 10	Kick Starter	11
Fig. 11	Clutch	12
Fig. 12	Transmission	14
Fig. 13	Shift Cam - Fork	16
Fig. 14	Shift Shaft - Pedal	17

Fig. 31	Meter	38
Fig. 32	Headlight	39
Fig. 33	Taillight	40
Fig. 34	Electrical 1	41
Fig. 35	Handle Switch - Lever	43

INDEX


Numerical Index
Parts Name Index

CHASSIS

Fig. 15	Frame - Tool	18
Fig. 16	Front Fender - Rear Fender	19
Fig. 17	Side Cover	20
Fig. 18	Oil Tank	21
Fig. 19	Rear Arm	22
Fig. 20	Rear Suspension	23
Fig. 21	Crank Pedal	24
Fig. 22	Steering	25
Fig. 23	Front Fork	26
Fig. 24	Fuel Tank	28
Fig. 25	Seat - Carrier	30
Fig. 26	Front Wheel	31
Fig. 27	Rear Wheel	33
Fig. 28	Handlebar - Cable	35
Fig. 29	Stand - Footrest	36
Fig. 30	Flasher Light	37

FIG. 1 CYLINDER HEAD. CYLINDER

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5M3-11111-00	HEAD, cylinder 1	1	
2	5J1-11161-00	ABSORBER 1	1	
3	427-11161-00	ABSORBER 1	3	
4	1T9-11161-00	ABSORBER 1	2	
5	517-11181-00	GASKET, cylinder head 1	1	
6	94701-00039	PLUG, sPark (NGK B6HS)	1	
7	2L7-11311-00	CYLINDER 1	1	
8	353-11351-00	GASKET, cylinder	1	
9	90116-06026	BOLT, stud	4	
10	95301-06600	NUT	4	
11	92901-06200	WASHER, Plain	4	






FIG. 2 CRANKSHAFT•PISTON

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2U2-11400-00	CRANKSHAFT ASSY	1	
2	2U2-11412-00	*CRANK 1	1	
3	2U2-11422-00	*CRANK 2	1	
4	538-11651-01	*ROD, connecting	1	
5	93310-41809	*BEARING, cylindrical	1	
6	257-11681-00	*PIN, crank 1	1	
7	90209-18112	*WASHER	2	
8	5L3-11631-00-96	PISTON (STD)	1	UR
	5L3-11631-00-98	PISTON (STD)	1	UR
	5L3-11635-00	PISTON (1ST O/S 0.25MM)	1	AP
	5L3-11636-00	PISTON (2ND O/S 0.50MM)	1	AP
9	517-11633-00	PIN, piston	1	
10	260-11610-02	PISTON RING SET (STD)	1	
	260-11610-12	PISTON RING SET (1ST O/S)	1	AP
	260-11610-22	PISTON RING SET (2ND O/S)	1	AP
11	93450-13022	CIRCLIP	2	
12	93310-11268	BEARING, cylindrical	1	
13	90280-03017	KEY, woodruff	1	
14	93306-20418	BEARING (B6204CS)	2	
15	93102-20009	OIL SEAL	1	UR
	93102-20155	OIL SEAL	1	UR
16	93103-28011	OIL SEAL	1	UR
	93103-28100	OIL SEAL	1	UR

FIG. 3 FLY WHEEL MAGNETO

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5G0-81300-20	FLYWHEEL MAGNETO ASSY	1	
2	5G0-81350-20	•ROTOR ASSY	1	
3	520-81309-20	•BASE, magneto	1	
4	511-81312-20	•COIL, source	1	
5	5A3-81313-20	•COIL, lighting 1	1	
6	2A6-81321-20	•CONTACT BREAKER ASSY	1	
7	1K8-81325-20	•CONDENSER 1	1	
8	116-81331-20	•LUBRICATOR	1	
9	5G1-81315-20	•LEAD WIRE ASSY	1	
10	97602-04125	•SCREW, Pan head with washer	4	
11	110-81346-21	•SCREW, Pan head	1	
12	110-81347-21	•SCREW, Pan head	1	
13	110-81345-21	•SCREW, Pan head	1	
14	98701-05016	SCREW, flat head	2	
15	90201-12535	WASHER, Plate	1	
16	92901-12100	WASHER, spring	1	
17	90170-12175	NUT	1	




FIG. 4 OIL PUMP

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	4U1-13101-01	OIL PUMP ASSY	1	
2	93505-32002	•BALL	1	
3	90501-02217	•SPRING, compression	1	
4	90445-05529	•HOSE	1	
5	353-13552-01	•NOZZLE	1	
6	90468-02033	•CLIP	1	
7	90430-04004	•GASKET	1	
8	98901-04008	•SCREW, blind	1	
9	137-13138-01	•PLATE, adjusting	1	
10	137-13137-00-03	•SHIM (0.3T)	1	UN
11	92901-05100	•WASHER, spring	1	
12	95301-05600	•NUT	1	
13	367-13146-01	•COVER, adjust Pulley	1	
14	2A3-13175-00	SHAFT, worm	1	
15	90201-08624	WASHER, Plate	1	
16	126-13116-00	GASKET, Pump case	1	
17	98501-05016	SCREW, Pan head	2	
18	93101-10001	OIL SEAL	1	
19	1E7-13176-00	METAL, worm shaft outer	1	
20	353-13178-00	GEAR, Pump drive (28T)	1	
21	93603-22028	PIN, dowel	1	
22	93430-08006	CIRCLIP	1	
23	248-13174-00	HOLDER, oil Pipe	1	
24	90201-10135	WASHER, Plate	2	
25	367-13174-00	HOLDER, oil Pipe	1	






FIG. 5 INTAKE



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2A3-13610-01	REED VALVE ASSY	1	
2	2A3-13613-00	*REED, valve	1	
3	2A3-13616-00	*STOPPER, reed valve	1	
4	97602-03108	*SCREW, Pan head with washer	3	
5	353-13621-00	GASKET, valve seat	2	
6	1G5-13505-00	JOINT, Pump	1	
7	90468-02033	CLIP	1	
8	92501-06020	SCREW, Pan head	4	
9	5L1-14453-00	JOINT, air cleaner 1	1	
10	90460-33087	CLAMP, hose	1	
11	90460-51059	CLAMP, hose	1	
12	3T2-14411-01	CASE, air cleaner 1	1	
13	5J1-14412-00	CAP, cleaner case 1	1	
14	3T2-14451-00	ELEMENT, air cleaner	1	
15	3T2-14452-00	SEAL	1	
16	92506-06018	SCREW, Pan head	3	
17	92906-06600	WASHER, Plate	3	
18	3T2-14437-00	DUCT	1	
19	90119-06044	BOLT, with washer	4	
20	97301-06016	BOLT	1	
21	92901-06600	WASHER, Plate	1	

FIG. 6 CARBURETOR



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5M3-14301-00	CARBURETOR ASSY 1	1	
2	367-14169-00	*CAP	1	
3	288-14124-00	*SCREW, cable adjusting	1	
4	288-14161-00	*NUT, cable adjusting	1	
5	4U1-14126-00	*GASKET	1	
6	1G3-14312-15	*VALVE, throttle 1	1	
7	367-14331-00	*SPRING, throttle valve	1	
8	367-14136-02	*SEAT, spring	1	
9	2T4-14336-01	*NEEDLE	1	
10	288-14137-00	*CLIP	1	
11	5L3-14341-00	*NOZZLE, main	1	
12	367-14342-18	*JET, Pilot (#036)	1	
13	367-14390-14	*NEEDLE VALVE ASSY	1	
14	288-14343-42	*JET, main (#084)	1	UR STD
	288-14343-41	*JET, main (#082)	1	UR
	288-14343-43	*JET, main (#086)	1	UR
15	367-14195-00	*WASHER, needle valve	1	
16	367-14386-00	*PIN, float	1	
17	1G5-14385-00	*FLOAT	1	
18	4U1-14384-00	*GASKET, float chamber	1	
19	367-14211-00	*SCREW, Pilot adjusting	1	
20	646-14212-01	*SPRING, Pilot adjusting	1	
21	367-14323-00	*SCREW, air adjusting	1	
22	367-14337-00	*SPRING, air adjusting	1	
23	367-14371-00	*PLUNGER, starter	1	
24	367-14335-00	*SPRING, Plunger	1	
25	367-14374-00	*CAP, Plunger	1	
26	626-14373-10	*COVER, Plunger cap	1	

FIG. 6 CARBURETOR

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27	367-14375-01	•LEVER, starter	1	
28	367-14377-00	•STOPPER	1	
29	367-14325-00	•SCREW, Pan head	4	
30	97311-06025	•BOLT	1	
31	4U1-14396-00	•PIPE	2	




FIG. 7 EXHAUST

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5M3-14610-10	EXHAUST PIPE ASSY 1	1	
2	132-14613-00	GASKET, exhaust Pipe	1	
3	97306-08020	BOLT	1	
4	92906-08600	WASHER, Plate	1	
5	5J1-14718-00	PROTECTOR, muffler 1	1	
6	90202-06010	WASHER, Plate	2	
7	90202-05005	WASHER, Plate	2	
8	98906-06010	SCREW, bind	2	
9	5J0-14753-00	SILENCER, exhaust	1	
10	3M7-14615-00	JOINT, exhaust 1	1	
11	5J1-14752-00	PIPE, outlet	1	
12	98501-05010	SCREW, Pan head	1	
13	92901-05100	WASHER, sPring	1	
14	92901-05600	WASHER, Plate	1	
15	5J1-14758-00	PROTECTOR, silencer	1	
16	98906-06008	SCREW, bind	2	
17	90202-06010	WASHER, Plate	4	





FIG. 8 CRANKCASE

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	353-15111-00	CRANKCASE 1	1	
2	92501-06050	SCREW, Pan head	8	
3	92501-06055	SCREW, Pan head	2	
4	92501-06025	SCREW, Pan head	1	
5	91830-22016	PIN, dowel	2	
6	90334-12009	PLUG, straight	2	
7	3T2-15484-01	CLAMP 2	1	
8	353-15121-02	CRANKCASE 2	1	
9	492-15387-00	STOPPER	1	
10	90340-12005	PLUG, straight screw	1	
11	90430-12038	GASKET	1	







FIG. 9 CRANKCASE COVER

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5L1-15411-00	COVER, crankcase 1	1	
2	5L1-15443-00	EMBLEM	1	
3	5L1-15428-00	COVER, chain case 2	1	
4	5L1-15435-00	EMBLEM	1	
5	92506-06030	SCREW, Pan head	3	
6	92506-06045	SCREW, Pan head	1	
7	5L1-17466-00	GUIDE, chain	1	
8	92506-06012	SCREW, Pan head	3	
9	91830-21014	PIN, dowel	2	
10	5L1-15415-00	COVER, generator	1	
11	98506-04006	SCREW, Pan head	2	
12	4U7-15421-00	COVER, crankcase 2	1	
13	92506-06030	SCREW, Pan head	6	
14	92506-06035	SCREW, Pan head	1	
15	92506-06040	SCREW, Pan head	2	
16	353-15451-00	GASKET, crankcase cover	1	
17	91830-21014	PIN, dowel	2	
18	353-15437-02	SCRAPER, oil	1	
19	4U7-15416-00	COVER, oil pump	1	
20	92506-06016	SCREW, Pan head	2	
21	353-15362-00	PLUG, oil level	1	
22	93210-21190	O-RING	1	

FIG. 10 KICK STARTER



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	4U1-15660-00	KICK AXLE ASSY	1	
2	353-15641-00	GEAR, kick (24T)	1	
3	90468-26038	CLIP	1	
4	4U1-15664-00	GUIDE, sPring	1	
5	90508-29323	SPRING, torsion	1	
6	93109-15001	DIL SEAL	1	
7	248-15668-00	STOPPER	1	
8	353-15651-00	GEAR, kick idle (25T)	1	
9	90201-12166	WASHER, Plate	1	
10	93410-12003	CIRCLIP	2	
11	5L1-15620-00	KICK CRANK ASSY	1	
12	5L1-15612-00	•LEVER, kick	1	
13	93440-10028	•CIRCLIP	1	
14	90504-18031	•SPRING, compression	1	
15	90209-10210	•WASHER	1	
16	156-15618-01	•COVER, kick lever	1	
17	97316-06025	BOLT	1	





FIG. 11 CLUTCH

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5L3-16300-00	CLUTCH ASSY	1	
2	5L3-16150-00	*PRIMARY DRIVEN GEAR COMP. (68T)	1	
3	257-16371-01	*BOSS, clutch	1	
4	131-16321-00	*PLATE, friction	2	
5	131-16324-00	*PLATE, clutch 1	1	
6	257-16351-00	*PLATE, Pressure 1	1	
7	90501-20122	*SPRING, compression	4	
8	90119-05001	*BOLT, with washer	4	
9	93210-99103	*O-RING	1	
10	122-16164-00	*PLATE, thrust 2	1	
11	90170-12060	NUT	1	
12	90208-12015	WASHER, conical spring	1	
13	90560-17123	SPACER	1	
14	122-16164-00	PLATE, thrust 2	1	
15	353-16111-01	GEAR, Primary drive (19T)	1	
16	90208-12015	WASHER, conical spring	1	
17	90179-12244	NUT	1	
18	90282-05005	KEY, straight	1	
19	137-16356-00	ROD, Push 1	1	
20	353-16357-00	ROD, Push 2	1	
21	93503-16010	BALL	1	
22	257-15389-00	SEAL, Push rod	1	
23	241-16341-01	SCREW, Push	1	
24	90113-06013	BOLT, set	1	
25	95301-06700	NUT	1	
26	5L1-16342-00	LEVER, Push	1	
27	90506-07066	SPRING, tension	1	
28	132-16346-00	HOOK, spring	1	

FIG. 11 CLUTCH

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	93104-11028	OIL SEAL	1	







FIG. 12 TRANSMISSION

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	353-17411-10	AXLE, main (12T)	1	
2	353-17121-11	GEAR, 2nd Pinion (17T)	1	
3	353-17131-00	GEAR, 3rd Pinion (21T)	1	UR
	353-17131-10	GEAR, 3rd Pinion (21T)	1	UR
4	353-17141-12	GEAR, 4th Pinion (24T)	1	
5	93440-16030	CIRCLIP	1	
6	93410-13004	CIRCLIP	1	
7	353-17471-00	PLATE, cover	1	
8	92501-06012	SCREW, Pan head	2	
9	93306-20303	BEARING (B6203Z)	1	
10	5L1-17421-00	AXLE, drive	1	
11	353-17211-01	GEAR, 1st wheel (39T)	1	
12	367-17221-00	GEAR, 2nd wheel (34T)	1	
13	353-17231-00	GEAR, 3rd wheel (30T)	1	
14	353-17241-00	GEAR, 4th wheel (27T)	1	
15	90387-16126	COLLAR	1	
16	257-17219-00	SHIM (0.6T)	1	
17	93440-16030	CIRCLIP	2	
18	93410-13004	CIRCLIP	1	
19	214-17428-00-09	SHIM 2 (0.9T)	1	
20	93306-30301	BEARING (B6303)	1	
21	93102-17187	OIL SEAL	1	
22	257-17461-11	SPROCKET, drive (11T)	1	
23	93410-16007	CIRCLIP	1	
24	90338-16015	PLUG	1	
25	97301-06010	BOLT	1	
26	93410-16007	CIRCLIP	1	
27	283-17492-00	DOG, transmission shift	1	

FIG. 12 TRANSMISSION



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	90501-12090	SPRING, compression	1	
29	283-17491-20	SPROCKET, drive	1	
30	93306-00203	BEARING (B6002)	1	
31	93410-15005	CIRCLIP	1	
32	283-17494-00	FORK, transmission shift	1	
33	90501-10078	SPRING, compression	1	
34	283-17495-00	LEVER, transmission shift	1	
35	283-17496-00	KNOB, transmission shift	1	
36	93430-08006	CIRCLIP	1	




FIG. 13 SHIFT CAM.FORK

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	4U1-18540-00	SHIFT CAM ASSY	1	
2	93604-10011	•PIN, dowel	4	
3	214-18561-00	•PLATE, side 1	1	
4	98701-05012	•SCREW, flat head	1	
5	93604-08071	•PIN, dowel	1	
6	374-18141-00	•PLATE, stopPer	1	
7	93440-12026	•CIRCLIP	1	
8	353-18562-00	PLATE, stopPer 2	1	
9	92701-06012	SCREW, flat head	2	
10	353-18511-01	FDRK, shift 1	1	
11	353-18512-01	FDRK, shift 2	1	
12	91401-25020	PIN, cotter	1	
13	93606-14081	PIN, dowel	2	
14	214-18531-00	BAR, shift fork guide 1	1	
15	93430-10016	CIRCLIP	2	
16	90109-14485	BOLT	1	
17	90501-09292	SPRING, compResion	1	
18	353-18547-00	STOPPER, cam	1	
19	137-15353-00	GASKET, drain	1	

FIG. 14 SHIFT SHAFT-PEDAL

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	4U1-18101-00	SHIFT SHAFT ASSY	1	
2	93430-10016	CIRCLIP	1	
3	353-18120-00	SHIFT LEVER ASSY	1	
4	214-18178-00	ROLLER, shift lever	1	
5	90508-32054	SPRING, torsion	1	
6	367-18197-00	SHAFT	1	
7	93430-10016	CIRCLIP	1	
8	90149-08094	SCREW	1	
9	95301-08600	NUT	1	
10	93101-12004	OIL SEAL	1	
11	90201-12575	WASHER, Plate	1	
12	93430-10016	CIRCLIP	1	
13	2J5-18111-00	PEDAL, shift	1	
14	132-18113-01	COVER, shift Pedal	1	
15	97326-06020	BOLT	1	






FIG. 15 FRAME• TOOL

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5M3-21110-00-33	FRAME COMP	1	yamaha black
2	95821-08090	BOLT, flange	2	
3	95821-08120	BOLT, flange	1	
4	95701-08100	NUT, flange	2	
5	92901-08100	WASHER, spring	2	
6	5J0-21471-00-98	PROTECTOR, engine	1	low gloss black
7	97306-06016	BOLT	2	
8	92906-06100	WASHER, spring	2	
9	92906-06600	WASHER, plate	2	
10	2E9-24182-00	DAMPER, locating 2	2	
11	90336-15033	PLUG, taper	2	
12	2U2-28100-10	TOOL KIT	1	
13	353-15361-00	GAUGE, level	1	



FWD

FIG. 16 FRONT FENDER•REAR FENDER



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5M3-21511-00	FENDER, front	1	UR white
	5M3-21511-10	FENDER, front	1	UR yamaha black
2	90201-06067	WASHER, Plate	4	
3	97301-06020	BOLT	4	
4	92901-06100	WASHER, sPring	4	
5	5M3-21611-00	FENDER, rear	1	UR white
	5M3-21611-10	FENDER, rear	1	UR yamaha black
6	5J1-21617-00	BRACKET, fender	1	
7	5M3-21621-00	FLAP	1	
8	5M3-21618-00	REINFORCEMENT, rear 2	1	
9	97306-08040	BOLT	2	
10	92906-08600	WASHER, Plate	2	
11	95701-08100	NUT, flange	2	
12	97321-06025	BOLT	2	
13	90201-06067	WASHER, Plate	2	
14	92506-06020	SCREW, Pan head	2	
15	92506-06012	SCREW, Pan head	2	
16	90201-06053	WASHER, Plate	4	
17	95701-06100	NUT, flange	2	

FIG. 17 SIDE COVER

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5J0-21711-00-98	COVER, side 1	1	UR white, low gloss black
	5J0-21711-10	COVER, side 1	1	UR yamaha black
	5J0-21711-10-E1	COVER, side 1	1	UR chaPPy red
2	5J0-21721-00	COVER, side 2	1	UR white
	5J0-21721-10	COVER, side 2	1	UR yamaha black
	5J0-21721-10-E1	COVER, side 2	1	UR chaPPy red
3	5J0-2173E-00	GRAPHIC 1	1	UR for white
	5J0-2173E-10	GRAPHIC 1	1	UR for yamaha black
	5J0-2173E-20	GRAPHIC 1	1	UR for chaPPy red
4	5J0-2173F-00	GRAPHIC 2	1	UR for white
	5J0-2173F-10	GRAPHIC 2	1	UR for yamaha black
	5J0-2173F-20	GRAPHIC 2	1	UR for chaPPy red
5	2L4-21737-01	EMBLEM	2	
6	90480-12053	GROMMET	6	





FIG. 18 OIL TANK

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5J0-21751-00	TANK, oil	1	
2	1Y1-21764-00	LENS, level gauge	1	
3	1Y1-21763-00	GASKET, level gauge	1	
4	1Y1-2176A-00	REFLECTOR, level gauge	1	
5	2A6-21796-00	HINGE	1	
6	92501-06015	SCREW, Pan head	2	
7	92901-06100	WASHER, spring	2	
8	92901-06600	WASHER, plate	2	
9	91701-05050	PIN, clevis	1	
10	90468-10050	CLIP	1	
11	1T9-21771-00	BODY, cap	1	
12	90445-09586	HOSE	1	
13	4J2-21745-00	PIPE, oil tank breather	1	
14	90201-06067	WASHER, plate	1	
15	90467-08003	CLIP	2	
16	90122-06015	BOLT, wing	1	
17	90179-06013	NUT	1	






FIG. 19 REAR ARM

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5M3-22110-00-35	REAR ARM COMP.	1	silver
2	102-22123-00	BUSH 1	2	
3	4G3-22151-00	SEAL, Guard	1	
4	3T2-22141-01	SHAFT, Pivot	1	
5	92901-10100	WASHER, sPring	1	
6	95601-10100	NUT, u	1	
7	90387-100F8	COLLAR	1	
8	5J0-22311-00	CASE, chain	1	
9	92506-06010	SCREW, Pan head	2	
10	90201-06053	WASHER, Plate	2	
11	120-27431-00	FOOTREST, rear 1	2	
12	90240-06009	PIN, clevis	2	
13	91401-16012	PIN, cotter	2	
14	120-27433-00	COVER, rear footrest	2	
15	90201-20279	WASHER, Plate	2	

FIG. 20 REAR SUSPENSION

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5J0-22210-01	SHOCK ABSORBER ASSY, rear	1	
2	90240-10072	PIN, clevis	1	
3	90240-10069	PIN, clevis	1	
4	92901-10600	WASHER, Plate	2	
5	91401-25020	PIN, cotter	2	






FIG. 21 CRANK PEDAL

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5L1-27810-00	CRANK, Pedal	1	
2	5L1-27821-00	PEDAL, crank (R.H)	1	
3	283-27812-00	AXLE, Pedal	1	
4	283-27824-00	PIPE, shaft	1	
5	90501-20132	SPRING, comPression	1	
6	90251-07001	PIN, taPered	1	
7	90249-06005	PIN	1	
8	95301-06600	NUT	1	
9	92901-06600	WASHER, Plate	1	
10	93440-25019	CIRCLIP	2	
11	93430-15023	CIRCLIP	1	
12	283-27826-00	COVER, Pedal	1	
13	1F1-27850-00	PEDAL ASSY (L.H)	1	
14	1F1-27860-00	PEDAL ASSY (R.H)	1	
15	94504-10044	CHAIN	1	
16	94604-10001	•JOINT, chain	1	



FWD

FIG. 22 STEERING



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	156-23411-00	RACE, ball 1	1	
2	156-23412-00	RACE, ball 2	1	
3	93501-04011	BALL	19	
4	122-23411-00	RACE, ball 1	1	
5	122-23412-00	RACE, ball 2	1	
6	93503-16010	BALL	22	
7	90179-25033	NUT	1	
8	122-23416-00	COVER, ball race 2	1	
9	5J0-23435-00-33	CROWN, handle	1	yamaha black
10	1E6-23441-00-98	HOLDER, handle upper	2	low gloss black
11	97326-08030	BOLT	6	
12	92906-08600	WASHER, Plate	6	
13	90105-14202	BOLT, washer based	1	
14	584-23408-00	STEERING LOCK ASSY	1	
15	584-23484-01	CAP, handle lock	1	
16	90208-04029	WASHER, conical spring	1	
17	90269-04003	RIVET	1	
18	90502-09024	SPRING, conical	1	
19	5J0-23327-01	STAY, flasher	1	
20	5J0-23328-01	STAY, flasher	1	
21	5J0-23137-00	GASKET, upper cover 1	2	
22	5J0-23385-00	WASHER, special 1	2	
23	5J0-23318-00	HOLDER, cable 1	1	
24	97306-06016	BOLT	1	
25	92906-06100	WASHER, spring	1	
26	92906-06600	WASHER, Plate	1	





FIG. 23 FRONT FORK


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5J0-23102-00	FRONT FORK ASSY (L.H.)	1	
2	5J0-23124-00	•TUBE, inner 1	1	
3	5J0-23191-00	•BOOT	1	
4	509-23194-L0	•SCREW, boot band	1	
5	5J0-23192-00	•BAND	1	
6	2Y1-23114-00	•GASKET	1	
7	5J0-23112-00	•WASHER, caP	1	
8	5G0-23111-00	•BOLT, caP	1	
9	5J0-23141-00	•SPRING, front fork	1	
10	1E5-92072-70	•SPACER	1	
11	5J0-23146-00	•WASHER, oil seal	1	
12	5J0-23126-00	•TUBE, outer 1	1	
13	5J0-23149-00	••WASHER, sPring upper	1	
14	3V3-23156-00	••CLIP, oil seal	1	
15	5F6-23145-00	••OIL SEAL	1	
16	5J0-23103-00	FRONT FORK ASSY (R.H.)	1	
17	5J0-23136-00	•TUBE, outer 2	1	
18	5J0-23149-00	••WASHER, sPring upper	1	
19	3V3-23156-00	••CLIP, oil seal	1	
20	5F6-23145-00	••OIL SEAL	1	
21	5J0-23124-00	•TUBE, inner 1	1	
22	5J0-23191-00	•BOOT	1	
23	509-23194-L0	•SCREW, boot band	1	
24	5J0-23192-00	•BAND	1	
25	2Y1-23114-00	•GASKET	1	
26	5J0-23112-00	•WASHER, caP	1	
27	5G0-23111-00	•BOLT, caP	1	
28	5J0-23141-00	•SPRING, front fork	1	

FIG. 23 FRONT FORK



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	1E5-92072-70	•SPACER	1	
30	5J0-23146-00	•WASHER oil seal	1	
31	5J1-23340-00	UNDER BRACKET COMP.	1	
32	5J0-23346-00	BOLT 1	2	
33	5J0-23317-00	HOLDER, cable	1	

FIG. 24 FUEL TANK



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5J0-24110-00-01	FUEL TANK COMP.	1	UR white
	5J0-24110-00-02	FUEL TANK COMP.	1	UR yamaha black
	5J0-24110-00-03	FUEL TANK COMP.	1	UR chaPPy red
2	5J0-24240-01	•GRAPHIC SET	1	UR for w
	5J0-24240-11	•GRAPHIC SET	1	UR for yb
	5J0-24240-21	•GRAPHIC SET	1	UR for cPr
3	4U5-24181-00	DAMPER, locatinG 1	2	
4	5J0-24182-00	DAMPER, locatinG 2	1	
5	90387-06553	COLLAR	1	
6	97301-06030	BOLT	1	
7	92901-06100	WASHER, sPring	1	
8	5J0-24186-00	WASHER, sPecial	1	
9	5G0-24500-00	FUEL COCK ASSY 1	1	
10	4X8-24524-00	•LEVER, cock	1	
11	4X8-24525-00	•PLATE, lever fitting	1	
12	357-24529-10	•SPRING	1	
13	4X8-24533-00	•SEAL, cock	1	
14	4X8-24521-00	•CUP, filter	1	
15	4X8-24565-00	•GASKET	1	
16	4X8-24512-00	•GASKET	1	
17	4X8-24535-00	•SCREW, lever fitting	2	
18	4X8-24515-00	•NET, filter 2	1	
19	90149-06008	SCREW	2	
20	90202-06010	WASHER, Plate	2	
21	90445-09079	HOSE	1	
22	90467-08003	CLIP	2	
23	2A6-24611-00	BODY, caP	1	
24	1W1-24612-00	GASKET, caP	1	

FIG. 24 FUEL TANK

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25	90445-09115	HOSE	1	






FIG. 25 SEAT CARRIER



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5J0-W2472-00	DOUBLE SEAT ASSY	1	
2	5J0-24731-00	COVER, double seat	1	
3	5J0-24754-00	HOOK, seat	1	
4	5J0-2472E-00	SUPPORT, tool	1	
5	90387-10661	COLLAR	2	
6	95806-08020	BOLT, flange	2	
7	5J0-24830-00-98	SUB CARRIER ASSY	1	low gloss black
8	5J0-21308-00	HELMET HANGER ASSY	1	
9	92701-06018	SCREW, flat head	1	
10	5J0-24734-00	BAND, seat	1	
11	5J0-24736-00	WASHER	2	
12	97306-08020	BOLT	2	
13	92906-08100	WASHER, spring	2	

FIG. 26 FRONT WHEEL


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5J0-25111-00-98	HUB, front	1	low gloss black
2	90560-12208	SPACER	1	
3	109-25315-00	FLANGE, spacer	1	
4	93306-30103	BEARING (B6301Z)	2	
5	93102-18008	OIL SEAL	1	
6	5J0-25121-00-98	PLATE, brake shoe	1	low gloss black
7	326-25330-10	BRAKE SHOE COMP.	2	
8	90506-16150	SPRING, tension	2	
9	5M3-25135-00	GEAR, drive	1	
10	109-25136-00	BUSH	1	
11	5M3-25138-00	GEAR, meter	1	
12	93104-07003	OIL SEAL	1	
13	90201-07076	WASHER, plate	1	
14	90201-20269	WASHER, plate	2	
15	183-25149-00	CLUTCH, meter	1	
16	93410-20009	CIRCLIP	1	
17	2N3-25155-00	LEVER, camshaft 1	1	
18	90101-06278	BOLT	1	
19	95301-06600	NUT	1	
20	3Y6-25351-00	CAMSHAFT	1	
21	3Y6-2533A-01	PLATE, indicator	1	
22	93105-47007	OIL SEAL	1	
23	5M3-25104-00	SPOKE SET, front	1	
24	94416-18297	RIM (1.60-18)	1	
25	2K5-25118-00	COVER, hub dust	1	
26	5J0-25181-00	AXLE, wheel	1	
27	90171-12005	NUT, castle	1	
28	91401-30025	PIN, cotter	1	



FWD

FIG. 26 FRONT WHEEL

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90387-12283	COLLAR	1	
30	102-25137-00	RING, stop	1	
31	93210-14104	O-RING	1	
32	94125-18264	TIRE (2.50-18)	1	
33	94225-18076	TUBE (2.50-18)	1	
34	94325-18059	BAND, rim (2.50-18)	1	






FIG. 27 REAR WHEEL

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5J0-25311-00-98	HUB, rear	1	low gloss black
2	109-25315-00	FLANGE, sPacer	1	
3	90560-12207	SPACER	1	
4	93306-30101	BEARING (B6301)	2	
5	93106-20002	OIL SEAL	1	
6	492-25447-10-33	SPROCKET, driven (47T)	1	UR STD
	492-25448-10-33	SPROCKET, driven (48T)	1	yamaha black UR yamaha black
7	90116-08283	BOLT, stud	4	
8	2A3-25412-00	WASHER	2	
9	90170-08158	NUT	4	
10	93104-21016	OIL SEAL	1	
11	1M3-25321-01-98	PLATE, brake shoe	1	low gloss black
12	326-25330-10	BRAKE SHOE COMP.	2	
13	90506-16150	SPRING, tension	2	
14	3Y6-25351-00	CAMSHAFT	1	
15	538-25355-00	LEVER, camshaft	1	
16	90101-06278	BOLT	1	
17	95301-06600	NUT	1	
18	3Y6-2533A-01	PLATE, indicator	1	
19	94416-18296	RIM (1.60-18)	1	
20	5J0-25304-00	SPOKE SET, rear	1	
21	94580-13110	CHAIN (DID420M 110L)	1	
22	94604-20001	*JOINT, chain	1	
23	5J0-25371-00	BAR, tension	1	
24	90109-08183	BOLT	1	
25	90109-08368	BOLT	1	
26	95301-08700	NUT	2	
27	92901-08100	WASHER, sPring	2	





FIG. 27 REAR WHEEL

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	91401-20015	PIN, cotter	2	
29	367-25381-00	AXLE, wheel	1	
30	90171-12005	NUT, castle	1	
31	91401-30025	PIN, cotter	1	
32	90387-12094	COLLAR	1	
33	90387-12670	COLLAR	1	
34	102-25389-00	PULLER, chain 2	2	
35	95301-06600	NUT	2	
36	92901-06100	WASHER, spring	2	
37	92901-06600	WASHER, plate	2	
38	94130-18686	TIRE (3.00-18)	1	
39	94227-18185	TUBE (2.75-18)	1	
40	94327-18116	BAND, rim (2.75-18)	1	

FIG. 28 HANDLEBAR·CABLE



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5M3-26111-00	HANDLEBAR	1	
2	3T5-26243-00	TUBE, throttle guide	1	
3	2N3-26242-00	GRIP (R.H)	1	
4	2N3-26241-00	GRIP (L.H)	1	
5	4U1-26261-00	CONNECTOR, cable	1	
6	5M3-26311-00	CABLE, throttle 1	1	
7	5J0-26312-00	CABLE, throttle 2	1	
8	5J0-26321-00	CABLE, pump	1	
9	4G3-26339-00	BOOT	1	
10	90170-10038	NUT	1	
11	5M3-26335-00	CABLE, clutch	1	
12	92901-06600	WASHER, plate	1	
13	164-26363-00	END, cable	1	
14	5M3-26341-00	CABLE, brake	1	
15	90179-06176	NUT	1	
16	3M7-26342-00	BOOT, cable	1	
17	90501-09052	SPRING, compression	1	
18	90249-12008	PIN	1	
19	1Y1-26290-10	MIRROR ASSY (L.H)	1	
20	1Y1-26290-00	MIRROR ASSY (R.H)	1	AP
21	90338-09012	PLUG	1	
22	2X1-26124-00	PROTECTOR, handlebar	1	
23	437-83936-10	BAND, switch cord	2	





FIG. 29 STAND•FOOTREST

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5J0-27211-00-90	PEDAL, brake	1	uni chrome (black)
2	90508-32354	SPRING, torsion	1	
3	90201-14212	WASHER, Plate	1	
4	93430-10015	CIRCLIP	1	
5	5J0-27231-01	ROD, brake	1	
6	92901-06600	WASHER, Plate	1	
7	91401-20015	PIN, cotter	1	
8	90501-10245	SPRING, compression	1	
9	90249-12008	PIN	1	
10	90179-06176	NUT	1	
11	5M3-27311-00-33	STAND, side	1	yamaha black
12	90109-08031	BOLT	1	
13	90506-25047	SPRING, tension	1	
14	95301-08700	NUT	1	

FWD


FIG. 30 FLASHER LIGHT



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5A2-83310-10	FRONT FLASHER LIGHT ASSY 1	2	
2	3M7-83312-10	•LENS, flasher	1	
3	152-83311-10	•BULB (6V-10W)	1	
4	1H2-83346-00	CORD	2	
5	1M1-83318-00	STAY, flasher 1	2	
6	95303-08800	NUT, crown	2	
7	3M7-83310-10	REAR FLASHER LIGHT ASSY 1	2	
8	152-83311-10	•BULB (6V-10W)	1	
9	3M7-83312-10	•LENS, flasher	1	
10	95701-08100	NUT, flange	2	


FIG. 31 METER

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5M3-83510-F0	SPEEDOMETER ASSY	1	
2	5M3-83520-00	•SOCKET CORD ASSY	1	
3	122-83516-10	•BULB (6V-3W)	3	
4	5J0-83519-00	BRACKET, meter	1	
5	5J0-83513-00	DAMPER	2	
6	355-83524-00	WASHER, sPecial	2	
7	95301-06600	NUT	2	
8	97301-08016	BOLT	2	
9	92901-08100	WASHER, sPring	2	
10	3H6-83550-00	SPEEDOMETER CABLE ASSY	1	



FWD

FIG. 32 HEADLIGHT



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5M3-84110-40	HEADLIGHT UNIT ASSY	1	
2	5M3-84120-40	•LENS ASSY	1	
3	5J0-84195-20	•RING, retaining	1	
4	3Y3-84112-30	•SOCKET	1	
5	148-84324-00	•SPRING, reflector	3	
6	1M1-84133-60	•COLLAR, screw	1	
7	5M3-84114-40	•BULB, headlight (6V-25/25W)	1	
8	5J0-84130-20	BODY ASSY, headlight	1	UR white
	5J0-84130-30	BODY ASSY, headlight	1	UR yamaha black
	5J0-84130-40	BODY ASSY, headlight	1	UR chaPPy red
9	5J0-84145-20	•COLLAR, body fitting	2	
10	1M1-84137-60	BOLT, sPecial	1	
11	90110-08044	BOLT, hexagon socket head	2	
12	90201-085E6	WASHER, Plate	2	
13	5J0-28391-00	GRAPHIC, headlight body	1	UR white
	5J0-28391-10	GRAPHIC, headlight body	1	UR yamaha black
	5J0-28391-20	GRAPHIC, headlight body	1	UR chaPPy red






FIG. 33 TAILLIGHT

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	97301-05010	BOLT	2	
2	92901-05100	WASHER, sPring	2	
3	1X4-84510-90	TAILLIGHT UNIT ASSY	1	
4	1X6-84511-00	•BASE, taillight	1	
5	1X4-84521-90	•LENS, taillight	1	
6	1X4-84524-90	•SCREW, lens fitting	2	
7	1X4-84514-00	•BULB (6V-2W)	1	
8	1X4-84535-00	•BULB (6V-5W)	1	
9	5M3-84519-90-33	BRACKET, taillight	1	yamaha black
10	2E1-84517-00	CORD, taillight	1	
11	97301-06016	BOLT	2	
12	92901-06100	WASHER, sPring	2	
13	90201-06052	WASHER, Plate	2	




FIG. 34 ELECTRICAL 1

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	353-81970-50	RECTIFIER ASSY	1	UR
	353-81970-63	RECTIFIER ASSY	1	UR
2	98501-05020	SCREW, Pan head	1	
3	92901-05100	WASHER, sPring	1	
4	92901-05600	WASHER, Plate	1	
5	4F4-81910-60	VOLTAGE REGULATOR ASSY	1	
6	92501-06015	SCREW, Pan head	1	
7	92901-06100	WASHER, sPring	1	
8	92901-06600	WASHER, Plate	1	
9	437-82110-22	BATTERY ASSY	1	
10	90445-08171	HOSE	1	
11	3T2-82129-01	COVER, battery	1	
12	90201-06053	WASHER, Plate	1	
13	92506-06016	SCREW, Pan head	1	
14	3T2-82122-00	SEAT, battery	1	
15	353-82150-00	FUSE HOLDER ASSY	1	
16	116-82151-00	*FUSE (6V-10A)	1	
17	1K8-82310-40	IGNITION COIL ASSY	1	
18	92501-06020	SCREW, Pan head	2	
19	92902-06100	WASHER, sPring	2	
20	1J7-82370-10	PLUG CAP ASSY	1	with noise suP-Presser
21	5M3-82508-20	MAIN SWITCH ASSY	1	
22	98902-04010	SCREW, bind	2	
23	341-82540-01	NEUTRAL SWITCH ASSY	1	
24	341-82543-00	*GASKET	1	
25	1A0-82530-00	STOP SWITCH ASSY	1	
26	5M3-82590-20	WIRE HARNESS ASSY	1	
27	3K7-81980-00	*DIODE	1	




FIG. 34 ELECTRICAL 1

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	437-83936-00	BAND, switch cord	1	
29	2M5-83350-11	FLASHER RELAY ASSY	1	
30	469-83382-00	BELL	1	

FIG. 35 HANDLE SWITCH-LEVER

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5M3-82910-30	LEVER HOLDER ASSY 1	1	
2	137-83912-02-38	*LEVER 1	1	
3	90149-05164	*SCREW	1	
4	98506-05030	*SCREW, Pan head	2	
5	95606-05100	*NUT, u	1	
6	5J0-W8292-30	LEVER HOLDER ASSY (R.H)	1	
7	137-83922-02-38	*LEVER 2	1	
8	90149-05164	*SCREW	1	
9	95606-05100	*NUT, u	1	
10	98506-05022	*SCREW, Pan head	1	
11	98506-05030	*SCREW, Pan head	1	
12	361-83980-30	FRONT STOP SWITCH ASSY	1	
13	437-83936-00	BAND, switch cord	2	




FIG. 35 HANDLE SWITCH+LEVER

REF. NO.	PART NO.	DESCRIPTION	Q.TY	REMARKS
1	5M3-52819-30	LEVER HOLDER ASSY	1	
2	107-93812-05-38	LEVER	1	
3	80148-02184	SCREW	1	
4	88806-08030	SCREW-PAT. HEAD	1	
5	88808-08100	NUT	1	
6	810-88585-30	LEVER HOLDER ASSY (R-H)	1	
7	107-93812-05-38	LEVER	1	
8	80148-02184	SCREW	1	
9	88808-08100	NUT	1	
10	88806-08030	SCREW-PAT. HEAD	1	
11	88806-08030	SCREW-PAT. HEAD	1	
12	781-13980-02	RIGHT STOP SWITCH ASSY	1	
13	431-43236-08	BARREL SWITCH BRKT	1	

JMPB parts

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
5J0-W2472-00	25- 1	1G3-14312-15	6- 6	353-15437-02	9-18
5J0-W8292-30	35- 6	367-14323-00	6-21	5L1-15443-00	9- 2
5M3-11111-00	1- 1	367-14325-00	6-29	353-15451-00	9-16
1T9-11161-00	1- 4	367-14331-00	6- 7	3T2-15484-01	8- 7
427-11161-00	1- 3	367-14335-00	6-24	5L1-15612-00	10-12
5J1-11161-00	1- 2	2T4-14336-01	6- 9	156-15618-01	10-16
517-11181-00	1- 5	367-14337-00	6-22	5L1-15620-00	10-11
2L7-11311-00	1- 7	5L3-14341-00	6-11	353-15641-00	10- 2
353-11351-00	1- 8	367-14342-18	6-12	353-15651-00	10- 8
2U2-11400-00	2- 1	288-14343-41	6-14	4U1-15660-00	10- 1
2U2-11412-00	2- 2	288-14343-42	6-14	4U1-15664-00	10- 4
2U2-11422-00	2- 3	288-14343-43	6-14	248-15668-00	10- 7
260-11610-02	2-10	367-14371-00	6-23	353-16111-01	11-15
260-11610-12	2-10	626-14373-10	6-26	5L3-16150-00	11- 2
260-11610-22	2-10	367-14374-00	6-25	122-16164-00	11-10
5L3-11631-00-96	2- 8	367-14375-01	6-27	5M3-21511-00	11-14
5L3-11631-00-98	2- 8	367-14377-00	6-28	5M3-21511-10	16- 1
517-11633-00	2- 9	4U1-14384-00	6-18	5M3-21611-00	16- 5
5L3-11635-00	2- 8	1G5-14385-00	6-17	5M3-21611-10	16- 5
5L3-11636-00	2- 8	367-14386-00	6-16	5J1-21617-00	16- 6
538-11651-01	2- 4	367-14390-14	6-13	5M3-21618-00	16- 8
257-11681-00	2- 6	4U1-14396-00	6-31	5M3-21621-00	16- 7
4U1-13101-01	4- 1	3T2-14411-01	5-12	5J0-21711-00-98	17- 1
126-13116-00	4-16	5J1-14412-00	5-13	5J0-21711-10	17- 1
137-13137-00-03	4-10	3T2-14437-00	5-18	5J0-21711-10-E1	17- 1
137-13138-01	4- 9	3T2-14451-00	5-14	5J0-21721-00	17- 2
367-13146-01	4-13	3T2-14452-00	5-15	5J0-21721-10	17- 2
248-13174-00	4-23	5L1-14453-00	5- 9	5J0-21721-10-E1	17- 2
367-13174-00	4-25	5M3-14610-10	7- 1	5J0-2173E-00	17- 3
2A3-13175-00	4-14	132-14613-00	7- 2	5J0-2173E-10	17- 3
1E7-13176-00	4-19	3M7-14615-00	7-10	5J0-2173E-20	17- 3
353-13178-00	4-20	5J1-14718-00	7- 5	5J0-2173F-00	17- 4
1G5-13505-00	5- 6	5J1-14752-00	7-11	5J0-2173F-10	17- 4
353-13552-01	4- 5	5J0-14753-00	7- 9	5J0-2173F-20	17- 4
2A3-13610-01	5- 1	5J1-14758-00	7-15	2L4-21737-01	17- 5
2A3-13613-00	5- 2	353-15111-00	8- 1	4J2-21745-00	18-13
2A3-13616-00	5- 3	353-15121-02	8- 8	5J0-21751-00	18- 1
353-13621-00	5- 5	137-15353-00	13-19	1Y1-2176A-00	18- 4
288-14124-00	6- 3	353-15361-00	15-13	1Y1-21763-00	18- 3
4U1-14126-00	6- 5	353-15362-00	9-21	1Y1-21764-00	18- 2
367-14136-02	6- 8	492-15387-00	8- 9	1T9-21771-00	18-11
288-14137-00	6-10	257-15389-00	11-22	2A6-21796-00	18- 5
288-14161-00	6- 4	5L1-15411-00	9- 1	5M3-22110-00-35	19- 1
367-14169-00	6- 2	5L1-15415-00	9-10	102-22123-00	19- 2
367-14195-00	6-15	4U7-15416-00	9-19	3T2-22141-01	19- 4
367-14211-00	6-19	4U7-15421-00	9-12	4G3-22151-00	19- 3
646-14212-01	6-20	5L1-15428-00	9- 3	5J0-22210-01	20- 1
5M3-14301-00	6- 1	5L1-15435-00	9- 4	5J0-22311-00	19- 8
				5J0-23102-00	23- 1
				5J0-23103-00	23-16

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
5G0-23111-00	23- 8	5J0-24182-00	24- 4	5G0-23111-00	23- 8
	23-27	5J0-24186-00	24- 8	5J0-23112-00	23- 7
	23- 7	5J0-24240-01	24- 2		23-26
	23-26	5J0-24240-11	24- 2	2Y1-23114-00	23- 6
	23- 6	5J0-24240-21	24- 2		23-25
	23-25	5G0-24500-00	24- 9	5J0-23124-00	23- 2
	23- 2	4X8-24512-00	24-16		23-21
	23-21	4X8-24515-00	24-18		23-12
	23-12	4X8-24521-00	24-14	5J0-23126-00	23-17
	23-17	4X8-24524-00	24-10	5J0-23136-00	22-21
	22-21	4X8-24525-00	24-11	5J0-23137-00	23- 9
	23- 9	367-24529-10	24-12	5J0-23141-00	23-28
	23-28	4X8-24533-00	24-13		23-15
	23-15	4X8-24535-00	24-17	5F6-23145-00	23-20
	23-20	4X8-24565-00	24-15		23-11
	23-11	2A6-24611-00	24-23	5J0-23146-00	23-30
	23-30	1W1-24612-00	24-24		23-13
	23-13	5J0-2472E-00	25- 4	5J0-23149-00	23-18
	23-18	5J0-24731-00	25- 2		23-14
	23-14	5J0-24734-00	25-10	3V3-23156-00	23-19
	23-19	5J0-24736-00	25-11		23- 3
	23- 3	5J0-24754-00	25- 3	5J0-23191-00	23-22
	23-22	5J0-24830-00-98	25- 7		23- 5
	23- 5	5M3-25104-00	26-23	5J0-23192-00	23-24
	23-24	5J0-25111-00-98	26- 1		23- 4
	23- 4	2K5-25118-00	26-25	509-23194-L0	23-23
	23-23	5J0-25121-00-98	26- 6		23-33
	23-33	5M3-25135-00	26- 9	5J0-23317-00	22-23
	22-23	109-25136-00	26-10	5J0-23318-00	22-19
	22-19	102-25137-00	26-30	5J0-23327-01	22-20
	22-20	5M3-25138-00	26-11	5J0-23328-01	23-31
	23-31	183-25149-00	26-15	5J1-23340-00	23-32
	23-32	2N3-25155-00	26-17	5J0-23346-00	22-22
	22-22	5J0-25181-00	26-26	5J0-23385-00	22-14
	22-14	5J0-25304-00	27-20	584-23408-00	22- 4
	22- 4	5J0-25311-00-98	27- 1	122-23411-00	22- 1
	22- 1	109-25315-00	27- 2	156-23411-00	22- 5
	22- 5		27-11	122-23412-00	22- 2
	22- 2	1M3-25321-01-98	27-21	156-23412-00	22- 8
	22- 8	3Y6-2533A-01	27-21	122-23416-00	22- 9
	22- 9		27-18	5J0-23435-00-33	22-10
	22-10	326-25330-10	26- 7	1E6-23441-00-98	22-15
	22-15		27-12	584-23484-01	24- 1
	24- 1	3Y6-25351-00	26-20	5J0-24110-00-01	24- 1
	24- 1		27-14	5J0-24110-00-02	24- 1
	24- 1	538-25355-00	27-15	5J0-24110-00-03	24- 1
	24- 3	5J0-25371-00	27-23	4U5-24181-00	24- 3
	15-10	367-25381-00	27-29	2E9-24182-00	15-10

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.
102-25389-00	27-34	4F4-81910-60	34- 5
2A3-25412-00	27- 8	353-81970-50	34- 1
492-25447-10-33	27- 6	353-81970-63	34- 1
492-25448-10-33	27- 6	3K7-81980-00	34-27
5M3-26111-00	28- 1	437-82110-22	34- 9
2X1-26124-00	28-22	3T2-82122-00	34-14
2N3-26241-00	28- 4	3T2-82129-01	34-11
2N3-26242-00	28- 3	353-82150-00	34-15
3T5-26243-00	28- 2	116-82151-00	34-16
4U1-26261-00	28- 5	1K8-82310-40	34-17
1Y1-26290-00	28-20	1J7-82370-10	34-20
1Y1-26290-10	28-19	5M3-82508-20	34-21
5M3-26311-00	28- 6	1A0-82530-00	34-25
5J0-26312-00	28- 7	341-82540-01	34-23
5J0-26321-00	28- 8	341-82543-00	34-24
5M3-26335-00	28-11	5M3-82590-20	34-26
4G3-26339-00	28- 9	5M3-82910-30	35- 1
5M3-26341-00	28-14	3M7-83310-10	30- 7
3M7-26342-00	28-16	5A2-83310-10	30- 1
164-26363-00	28-13	152-83311-10	30- 3
5J0-27211-00-90	29- 1		30- 8
5J0-27231-01	29- 5	3M7-83312-10	30- 2
5M3-27311-00-33	29-11		30- 9
120-27431-00	19-11	1M1-83318-00	30- 5
120-27433-00	19-14	1H2-83346-00	30- 4
5L1-27810-00	21- 1	2M5-83350-11	34-29
283-27812-00	21- 3	469-83382-00	34-30
5L1-27821-00	21- 2	5M3-83510-F0	31- 1
283-27824-00	21- 4	5J0-83513-00	31- 5
283-27826-00	21-12	122-83516-10	31- 3
1F1-27850-00	21-13	5J0-83519-00	31- 4
1F1-27860-00	21-14	5M3-83520-00	31- 2
2U2-28100-10	15-12	355-83524-00	31- 6
5J0-28391-00	32-13	3H6-83550-00	31-10
5J0-28391-10	32-13	137-83912-02-38	35- 2
5J0-28391-20	32-13	137-83922-02-38	35- 7
5G0-81300-20	3- 1	437-83936-00	34-28
520-81309-20	3- 3		35-13
511-81312-20	3- 4	437-83936-10	28-23
5A3-81313-20	3- 5	361-83980-30	35-12
5G1-81315-20	3- 9	5M3-84110-40	32- 1
2A6-81321-20	3- 6	3Y3-84112-30	32- 4
1K8-81325-20	3- 7	5M3-84114-40	32- 7
116-81331-20	3- 8	5M3-84120-40	32- 2
110-81345-21	3-13	5J0-84130-20	32- 8
110-81346-21	3-11	5J0-84130-30	32- 8
110-81347-21	3-12	5J0-84130-40	32- 8
5G0-81350-20	3- 2	1M1-84133-60	32- 6

PART NO.	REF. NO.	PART NO.	REF. NO.
1M1-84137-60	32-10	90201-07076	26-13
5J0-84145-20	32- 9	90201-085E6	32-12
5J0-84195-20	32- 3	90201-08624	4-15
148-84324-00	32- 5	90201-10135	4-24
1X4-84510-90	33- 3	90201-12166	10- 9
1X6-84511-00	33- 4	90201-12535	3-15
1X4-84514-00	33- 7	90201-12575	14-11
2E1-84517-00	33-10	90201-14212	29- 3
5M3-84519-90-33	33- 9	90201-20269	26-14
1X4-84521-90	33- 5	90201-20279	19-15
1X4-84524-90	33- 6	90202-05005	7- 7
1X4-84535-00	33- 8	90202-06010	7- 6
90101-06278	26-18		7-17
	27-16		24-20
90105-14202	22-13	90208-04029	22-18
90109-08031	29-12	90208-12015	11-12
90109-08183	27-24		11-18
90109-08368	27-25	90209-10210	10-15
90109-14485	13-16	90209-18112	2- 7
90110-08044	32-11	90240-06009	19-12
90113-06013	11-24	90240-10069	20- 3
90116-06026	1- 9	90240-10072	20- 2
90116-08283	27- 7	90249-06005	21- 7
90119-05001	11- 8	90249-12008	28-18
90119-06044	5-19		29- 9
90122-06015	18-16	90251-07001	21- 6
90149-05164	35- 3	90269-04003	22-17
	35- 8	90280-03017	2-13
90149-06008	24-19	90282-05005	11-18
90149-08094	14- 8	90334-12009	8- 6
90170-08158	27- 9	90336-15033	15-11
90170-10038	28-10	90338-09012	28-21
90170-12060	11-11	90338-16015	12-24
90170-12175	3-17	90340-12005	8-10
90171-12005	26-27	90387-06553	24- 5
	27-30	90387-100F8	19- 7
90179-06013	18-17	90387-10661	25- 5
90179-06176	28-15	90387-12094	27-32
	29-10	90387-12283	26-29
	11-17	90387-12670	27-33
90179-25033	22- 7	90387-16126	12-15
90201-06052	33-13	90430-04004	4- 7
90201-06053	16-16	90430-12038	8-11
	19-10	90445-05529	4- 4
	34-12	90445-08171	34-10
90201-06067	16- 2	90445-09079	24-21
	16-13	90445-09115	24-25
	18-14	90445-09586	18-12

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.
90460-33087	5-10	92501-06050	8- 2
90460-51059	5-11	92501-06055	8- 3
90467-08003	18-15	92506-06010	19- 9
	24-22	92506-06012	9- 8
90468-02033	4- 6		16-15
	5- 7	92506-06016	9-20
90468-10050	18-10		34-13
90468-26038	10- 3	92506-06018	5-16
90480-12053	17- 6	92506-06020	16-14
90501-02217	4- 3	92506-06030	9- 5
90501-09052	28-17		9-13
90501-09292	13-17	92506-06035	9-14
90501-10078	12-33	92506-06040	9-15
90501-10245	29- 8	92506-06045	9- 6
90501-12090	12-28	92701-06012	13- 9
90501-20122	11- 7	92701-06018	25- 9
90501-20132	21- 5	92901-05100	4-11
90502-09024	22-18		7-13
90504-18031	10-14		33- 2
90506-07066	11-27		34- 3
90506-16150	26- 8	92901-05600	7-14
	27-13		34- 4
90506-25047	29-13	92901-06100	16- 4
90508-29323	10- 5		18- 7
90508-32054	14- 5		24- 7
90508-32354	29- 2		27-36
90560-12207	27- 3		33-12
90560-12208	26- 2		34- 7
90560-17123	11-13	92901-06200	1-11
91401-16012	19-13	92901-06600	5-21
91401-20015	27-28		18- 8
	29- 7		21- 9
91401-25020	13-12		27-37
	20- 5		28-12
91401-30025	26-28		29- 6
	27-31		34- 8
91701-05050	18- 9	92901-08100	15- 5
91830-21014	9- 9		27-27
	9-17		31- 9
91830-22016	8- 5	92901-10100	19- 5
1E5-92072-70	23-10	92901-10600	20- 4
	23-29	92901-12100	3-16
92501-06012	12- 8	92902-06100	34-19
92501-06015	18- 6	92906-06100	15- 8
	34- 6		22-25
92501-06020	5- 8	92906-06600	5-17
	34-18		15- 9
92501-06025	8- 4		22-26

NUMERICAL INDEX

PART NO.	REF. NO.	PART NO.	REF. NO.	PART NO.	REF. NO.
92906-08100	25-13	93440-25019	21-10	97301-06016	33-11
92906-08600	7- 4	93450-13022	2-11	97301-06020	16- 3
	16-10	93501-04011	22- 3	97301-06030	24- 6
	22-12	93503-16010	11-21	97301-08016	31- 8
93101-10001	4-18		22- 6	97306-06016	15- 7
93101-12004	14-10	93505-32002	4- 2		22-24
93102-17187	12-21	93603-22028	4-21	97306-08020	7- 3
93102-18008	26- 5	93604-08071	13- 5		25-12
93102-20009	2-15	93604-10011	13- 2	97306-08040	16- 9
93102-20155	2-15	93606-14081	13-13	97311-06025	6-30
93103-28011	2-16	94125-18264	26-32	97316-06025	10-17
93103-28100	2-16	94130-18686	27-38	97321-06025	16-12
93104-07003	26-12	94225-18076	26-33	97326-06020	14-15
93104-11028	11-29	94227-18185	27-39	97326-08030	22-11
93104-21016	27-10	94325-18059	26-34	97602-03108	5- 4
93105-47007	26-22	94327-18116	27-40	97602-04125	3-10
93106-20002	27- 5	94416-18296	27-19	98501-05010	7-12
93109-15001	10- 6	94416-18297	26-24	98501-05016	4-17
93210-14104	26-31	94504-10044	21-15	98501-05020	34- 2
93210-21190	9-22	94580-13110	27-21	98506-04006	9-11
93210-99103	11- 9	94604-10001	21-16	98506-05022	35-10
93306-00203	12-30	94604-20001	27-22	98506-05030	35- 4
93306-20303	12- 9	94701-00039	1- 6		35-11
93306-20418	2-14	95301-05600	4-12	98701-05012	13- 4
93306-30101	27- 4	95301-06600	1-10	98701-05016	3-14
93306-30103	26- 4		21- 8	98901-04008	4- 8
93306-30301	12-20		26-19	98902-04010	34-22
93310-11268	2-12		27-17	98906-06008	7-16
93310-41809	2- 5		27-35	98906-06010	7- 8
93410-12003	10-10		31- 7		
93410-13004	12- 6	95301-06700	11-25		
	12-18	95301-08600	14- 9		
93410-15005	12-31	95301-08700	27-26		
93410-16007	12-23		29-14		
	12-26	95303-08800	30- 6		
93410-20009	26-16	95601-10100	19- 6		
93430-08006	4-22	95606-05100	35- 5		
	12-36		35- 9		
93430-10015	29- 4	95701-06100	16-17		
93430-10016	13-15	95701-08100	15- 4		
	14- 2		16-11		
	14- 7		30-10		
	14-12	95806-08020	25- 6		
93430-15023	21-11	95821-08090	15- 2		
93440-10028	10-13	95821-08120	15- 3		
93440-12026	13- 7	97301-05010	33- 1		
93440-16030	12- 5	97301-06010	12-25		
	12-17	97301-06016	5-20		

PARTS NAME INDEX

DESCRIPTION	REF. NO.
ABSORBER 1	1- 2
*	1- 3
*	1- 4
AXLE, drive	12-10
AXLE, main (12T)	12- 1
AXLE, Pedal	21- 3
AXLE, wheel	26-26
*	27-29
BALL	4- 2
*	11-21
*	22- 3
*	22- 6
BAND	23- 5
*	23-24
BAND, rim (2.50-18)	26-34
BAND, rim (2.75-18)	27-40
BAND, seat	25-10
BAND, switch cord	28-23
*	34-28
*	35-13
BAR, shift fork guide 1	13-14
BAR, tension	27-23
BASE, magneto	3- 3
BASE, taillight	33- 4
BATTERY ASSY	34- 9
BEARING (B6002)	12-30
BEARING (B6203Z)	12- 9
BEARING (B6204CS)	2-14
BEARING (B6301)	27- 4
BEARING (B6301Z)	26- 4
BEARING (B6303)	12-20
BEARING, cylindrical	2- 5
*	2-12
BELL	34-30
BODY ASSY, headlight	32- 8
*	32- 8
*	32- 8
BODY, caP	18-11
*	24-23
BOLT	5-20
*	6-30
*	7- 3
*	10-17
*	12-25
*	13-16
*	14-15

PARTS NAME INDEX

DESCRIPTION	REF. NO.
BOLT	15- 7
*	16- 3
*	16- 9
*	16-12
*	22-11
*	22-24
*	24- 6
*	25-12
*	26-18
*	27-16
*	27-24
*	27-25
*	29-12
*	31- 8
*	33- 1
*	33-11
BOLT 1	23-32
BOLT, caP	23- 8
*	23-27
BOLT, flange	15- 2
*	15- 3
*	25- 6
BOLT, hexagon socket head	32-11
BOLT, set	11-24
BOLT, sPecial	32-10
BOLT, stud	1- 9
*	27- 7
BOLT, washer based	22-13
BOLT, winG	18-16
BOLT, with washer	5-19
*	11- 8
BOOT	23- 3
*	23-22
*	28- 9
BOOT, cable	28-16
BOSS, clutch	11- 3
BRACKET, fender	16- 6
BRACKET, meter	31- 4
BRACKET, taillight	33- 9
BRAKE SHOE COMP.	26- 7
*	27-12
BULB (6V-10W)	30- 3
*	30- 8
BULB (6V-2W)	33- 7
BULB (6V-3W)	31- 3
BULB (6V-5W)	33- 8
BULB, headlight (6V-25/25W)	32- 7
BUSH	26-10

PARTS NAME INDEX

DESCRIPTION	REF. NO.
BUSH 1	19- 2
CABLE, brake	28-14
CABLE, clutch	28-11
CABLE, Pump	28- 8
CABLE, throttle 1	28- 6
CABLE, throttle 2	28- 7
CAMSHAFT	26-20
*	27-14
CAP	6- 2
CAP, cleaner case 1	5-13
CAP, handle lock	22-15
CAP, Plunger	6-25
CARBURETOR ASSY 1	6- 1
CASE, air cleaner 1	5-12
CASE, chain	19- 8
CHAIN	21-15
CHAIN (DID420M 110L)	27-21
CIRCLIP	2-11
*	4-22
*	10-10
*	10-13
*	12- 5
*	12- 6
*	12-17
*	12-18
*	12-23
*	12-26
*	12-31
*	12-36
*	13- 7
*	13-15
*	14- 2
*	14- 7
*	14-12
*	21-10
*	21-11
*	26-16
*	29- 4
CLAMP 2	8- 7
CLAMP, hose	5-10
*	5-11
CLIP	4- 6
*	5- 7
*	6-10
*	10- 3
*	18-10
*	18-15
*	24-22

PARTS NAME INDEX

PARTS NAME INDEX

PARTS NAME INDEX

DESCRIPTION	REF. NO.
CLIP, oil seal	23-14
*	23-19
CLUTCH ASSY	11- 1
CLUTCH, meter	26-15
COIL, lighting 1	3- 5
COIL, source	3- 4
COLLAR	12-15
*	19- 7
*	24- 5
*	25- 5
*	26-29
*	27-32
*	27-33
COLLAR, body fitting	32- 9
COLLAR, screw	32- 6
CONDENSER 1	3- 7
CONNECTOR, cable	28- 5
CONTACT BREAKER ASSY	3- 6
CORD	30- 4
CORD, taillight	33-10
COVER, adjust Pulley	4-13
COVER, ball race 2	22- 8
COVER, battery	34-11
COVER, chain case 2	9- 3
COVER, crankcase 1	9- 1
COVER, crankcase 2	9-12
COVER, double seat	25- 2
COVER, generator	9-10
COVER, hub dust	26-25
COVER, kick lever	10-16
COVER, oil Pump	9-19
COVER, Pedal	21-12
COVER, Plunger cap	6-26
COVER, rear footrest	19-14
COVER, shift Pedal	14-14
COVER, side 1	17- 1
*	17- 1
*	17- 1
COVER, side 2	17- 2
*	17- 2
*	17- 2
CRANK 1	2- 2
CRANK 2	2- 3
CRANK, Pedal	21- 1
CRANKCASE 1	8- 1
CRANKCASE 2	8- 8
CRANKSHAFT ASSY	2- 1
CROWN, handle	22- 9
CUP, filter	24-14
CYLINDER 1	1- 7

DESCRIPTION	REF. NO.
DAMPER	31- 5
DAMPER, locating 1	24- 3
DAMPER, locating 2	15-10
*	24- 4
DIODE	34-27
DOG, transmission shift	12-27
DOUBLE SEAT ASSY	25- 1
DUCT	5-18
ELEMENT, air cleaner	5-14
EMBLEM	9- 2
*	9- 4
*	17- 5
END, cable	28-13
EXHAUST PIPE ASSY 1	7- 1
FENDER, front	16- 1
*	16- 1
FENDER, rear	16- 5
*	16- 5
FLANGE, spacer	26- 3
*	27- 2
FLAP	16- 7
FLASHER RELAY ASSY	34-29
FLOAT	6-17
FLYWHEEL MAGNETO ASSY	3- 1
FOOTREST, rear 1	19-11
FORK, shift 1	13-10
FORK, shift 2	13-11
FORK, transmission shift	12-32
FRAME COMP	15- 1
FRONT FLASHER LIGHT ASSY 1	30- 1
FRONT FORK ASSY (L.H.)	23- 1
FRONT FORK ASSY (R.H.)	23-16
FRONT STOP SWITCH ASSY	35-12
FUEL COCK ASSY 1	24- 9
FUEL TANK COMP.	24- 1
*	24- 1
*	24- 1
FUSE (6V-10A)	34-16
FUSE HOLDER ASSY	34-15
GASKET	4- 7
*	6- 5
*	8-11
*	23- 6
*	23-25
*	24-15
*	24-16
*	34-24

DESCRIPTION	REF. NO.
GASKET, cap	24-24
GASKET, crankcase cover	9-16
GASKET, cylinder	1- 8
GASKET, cylinder head 1	1- 5
GASKET, drain	13-19
GASKET, exhaust Pipe	7- 2
GASKET, float chamber	6-18
GASKET, level Gauge	18- 3
GASKET, Pump case	4-16
GASKET, upper cover 1	22-21
GASKET, valve seat	5- 5
GAUGE, level	15-13
GEAR, drive	26- 9
GEAR, kick (24T)	10- 2
GEAR, kick idle (25T)	10- 8
GEAR, meter	26-11
GEAR, Primary drive (19T)	11-15
GEAR, Pump drive (28T)	4-20
GEAR, 1st wheel (39T)	12-11
GEAR, 2nd Pinion (17T)	12- 2
GEAR, 2nd wheel (34T)	12-12
GEAR, 3rd Pinion (21T)	12- 3
*	12- 3
GEAR, 3rd wheel (30T)	12-13
GEAR, 4th Pinion (24T)	12- 4
GEAR, 4th wheel (27T)	12-14
GRAPHIC SET	24- 2
*	24- 2
*	24- 2
GRAPHIC 1	17- 3
*	17- 3
*	17- 3
GRAPHIC 2	17- 4
*	17- 4
*	17- 4
GRAPHIC, headlight body	32-13
*	32-13
*	32-13
GRIP (L.H.)	28- 4
GRIP (R.H.)	28- 3
GROMMET	17- 6
GUIDE, chain	9- 7
GUIDE, spring	10- 4
HANDLEBAR	28- 1
HEAD, cylinder 1	1- 1
HEADLIGHT UNIT ASSY	32- 1
HELMET HANGER ASSY	25- 8
HINGE	18- 5

PARTS NAME INDEX

DESCRIPTION	REF. NO.
HOLDER, cable	23-33
HOLDER, cable 1	22-23
HOLDER, handle upper	22-10
HOLDER, oil pipe	4-23
*	4-25
HOOK, seat	25-3
HOOK, spring	11-28
HOSE	4-4
*	18-12
*	24-21
*	24-25
*	34-10
HUB, front	26-1
HUB, rear	27-1
IGNITION COIL ASSY	34-17
JET, main (#082)	6-14
JET, main (#084)	6-14
JET, main (#086)	6-14
JET, Pilot (#036)	6-12
JOINT, air cleaner 1	5-9
JOINT, chain	21-16
*	27-22
JOINT, exhaust 1	7-10
JOINT, pump	5-6
KEY, straight	11-18
KEY, woodruff	2-13
KICK AXLE ASSY	10-1
KICK CRANK ASSY	10-11
KNOB, transmission shift	12-35
LEAD WIRE ASSY	3-9
LENS ASSY	32-2
LENS, flasher	30-2
*	30-9
LENS, level gauge	18-2
LENS, taillight	33-5
LEVER HOLDER ASSY (R.H.)	35-6
LEVER HOLDER ASSY 1	35-1
LEVER 1	35-2
LEVER 2	35-7
LEVER, camshaft	27-15
LEVER, camshaft 1	26-17
LEVER, cock	24-10
LEVER, kick	10-12
LEVER, push	11-26
LEVER, starter	6-27
LEVER, transmission shift	12-34
LUBRICATOR	3-8
MAIN SWITCH ASSY	34-21

PARTS NAME INDEX

DESCRIPTION	REF. NO.
METAL, worm shaft outer	4-19
MIRROR ASSY (L.H.)	28-19
MIRROR ASSY (R.H.)	28-20
NEEDLE	6-9
NEEDLE VALVE ASSY	6-13
NET, filter 2	24-18
NEUTRAL SWITCH ASSY	34-23
NOZZLE	4-5
NOZZLE, main	6-11
NUT	1-10
*	3-17
*	4-12
*	11-11
*	11-17
*	11-25
*	14-9
*	18-17
*	21-8
*	22-7
*	26-19
*	27-9
*	27-17
*	27-26
*	27-35
*	28-10
*	28-15
*	29-10
*	29-14
*	31-7
NUT, cable adjusting	6-4
NUT, castle	26-27
*	27-30
NUT, crown	30-6
NUT, flange	15-4
*	16-11
*	16-17
*	30-10
NUT, u	19-6
*	35-5
*	35-9
O-RING	9-22
*	11-9
*	26-31
OIL PUMP ASSY	4-1
OIL SEAL	2-15
*	2-15
*	2-16
*	2-16

PARTS NAME INDEX

DESCRIPTION	REF. NO.
OIL SEAL	4-18
*	10-6
*	11-29
*	12-21
*	14-10
*	23-15
*	23-20
*	26-5
*	26-12
*	26-22
*	27-5
*	27-10
PEDAL ASSY (L.H.)	21-13
PEDAL ASSY (R.H.)	21-14
PEDAL, brake	29-1
PEDAL, crank (R.H.)	21-2
PEDAL, shift	14-13
PIN	21-7
*	28-18
*	29-9
PIN, clevis	18-9
*	19-12
*	20-2
*	20-3
PIN, cotter	13-12
*	19-13
*	20-5
*	26-28
*	27-28
*	27-31
*	29-7
PIN, crank 1	2-6
PIN, dowel	4-21
*	8-5
*	9-9
*	9-17
*	13-2
*	13-5
*	13-13
PIN, float	6-16
PIN, piston	2-9
PIN, tapered	21-6
PIPE	6-31
PIPE, oil tank breather	18-13
PIPE, outlet	7-11
PIPE, shaft	21-4
PISTON (STD)	2-8
*	2-8

PARTS NAME INDEX

DESCRIPTION	REF. NO.
PISTON (1ST O/S 0.25MM)	2- 8
PISTON (2ND O/S 0.50MM)	2- 8
PISTON RING SET (STD)	2-10
PISTON RING SET (1ST O/S)	2-10
PISTON RING SET (2ND O/S)	2-10
PLATE, adjusting	4- 9
PLATE, brake shoe	26- 6
*	27-11
PLATE, clutch 1	11- 5
PLATE, cover	12- 7
PLATE, friction	11- 4
PLATE, indicator	26-21
*	27-18
PLATE, lever fitting	24-11
PLATE, Pressure 1	11- 6
PLATE, side 1	13- 3
PLATE, stopper	13- 6
PLATE, stopper 2	13- 8
PLATE, thrust 2	11-10
*	11-14
PLUG	12-24
*	28-21
PLUG CAP ASSY	34-20
PLUG, oil level	9-21
PLUG, spark (NGK B6HS)	1- 6
PLUG, straight	8- 6
PLUG, straight screw	8-10
PLUG, taper	15-11
PLUNGER, starter	6-23
PRIMARY DRIVEN GEAR COMP. (68T)	11- 2
PROTECTOR, silencer	7-15
PROTECTOR, engine	15- 6
PROTECTOR, handlebar	28-22
PROTECTOR, muffler 1	7- 5
PULLER, chain 2	27-34
RACE, ball 1	22- 1
*	22- 4
RACE, ball 2	22- 2
*	22- 5
REAR ARM COMP.	19- 1
REAR FLASHER LIGHT ASSY 1	30- 7
RECTIFIER ASSY	34- 1
*	34- 1
REED VALVE ASSY	5- 1
REED, valve	5- 2
REFLECTOR, level gauge	18- 4
REINFORCEMENT, rear 2	16- 8
RIM (1.60-18)	26-24
*	27-19

PARTS NAME INDEX

DESCRIPTION	REF. NO.
RING, retaining	32- 3
RING, stop	26-30
RIVET	22-17
ROD, brake	29- 5
ROD, connecting	2- 4
ROD, Push 1	11-19
ROD, Push 2	11-20
ROLLER, shift lever	14- 4
ROTOR ASSY	3- 2
SCRAPER, oil	9-18
SCREW	14- 8
*	24-19
*	35- 3
*	35- 8
SCREW, air adjusting	6-21
SCREW, bind	4- 8
*	7- 8
*	7-16
*	34-22
SCREW, boot band	23- 4
*	23-23
SCREW, cable adjusting	6- 3
SCREW, flat head	3-14
*	13- 4
*	13- 9
*	25- 9
SCREW, lens fitting	33- 6
SCREW, lever fitting	24-17
SCREW, Pan head	3-11
*	3-12
*	3-13
*	4-17
*	5- 8
*	5-16
*	6-29
*	7-12
*	8- 2
*	8- 3
*	8- 4
*	9- 5
*	9- 6
*	9- 8
*	9-11
*	9-13
*	9-14
*	9-15
*	9-20
*	12- 8

PARTS NAME INDEX

DESCRIPTION	REF. NO.
SCREW, Pan head	16-14
*	16-15
*	18- 6
*	19- 9
*	34- 2
*	34- 6
*	34-13
*	34-18
*	35- 4
*	35-10
*	35-11
SCREW, Pan head with washer	3-10
*	5- 4
SCREW, Pilot adjusting	6-19
SCREW, Push	11-23
SEAL	5-15
SEAL, cock	24-13
SEAL, guard	19- 3
SEAL, Push rod	11-22
SEAT, battery	34-14
SEAT, spring	6- 8
SHAFT	14- 6
SHAFT, Pivot	19- 4
SHAFT, worm	4-14
SHIFT CAM ASSY	13- 1
SHIFT LEVER ASSY	14- 3
SHIFT SHAFT ASSY	14- 1
SHIM (0.3T)	4-10
SHIM (0.6T)	12-16
SHIM 2 (0.9T)	12-19
SHOCK ABSORBER ASSY, rear	20- 1
SILENCER, exhaust	7- 9
SOCKET	32- 4
SOCKET CORD ASSY	31- 2
SPACER	11-13
*	23-10
*	23-29
*	26- 2
*	27- 3
SPEEDOMETER ASSY	31- 1
SPEEDOMETER CABLE ASSY	31-10
SPOKE SET, front	26-23
SPOKE SET, rear	27-20
SPRING	24-12
SPRING, air adjusting	6-22
SPRING, compression	4- 3
*	10-14
*	11- 7
*	12-28
*	12-33